



Assembly Instructions

Buxton Round Fire Pit Accessory Pack

(Product Code: 61933053)

**PLEASE RETAIN THIS DOCUMENT ALONG WITH YOUR
PROOF OF PURCHASE FOR FUTURE REFERENCE**


Congratulations on your recent purchase of your beautiful Hartman furniture. We hope it brings you countless special moments with friends and family for many years to come.

Please follow these simple steps to build your furniture. We also have a very useful video available online to assist with the assembly, please visit www.hartmanuk.com

TOP TIPS



- Please read these instructions carefully before assembly, for further assistance please view our assembly video online for an easy step by step demonstration.
- Aluminium is a soft metal and over tightening may strip the thread or break the part, please loosely assembly your furniture before tightening to secure.
- Please **do not** use power tools, only use the tools provided in the bolt pack.
- Please allow 10 minutes for assembly.
- This furniture can be assembled with **1** person; however, you may need someone to assist you when turning the furniture over into position.

PARTS LIST

Components					Fixings				
Parts List	Parts Picture	Description	Qty	Part No.	Parts List	Parts Picture	Description	Qty	Part No.
A		Spark Guard	1	61933053A	D		Upper Grill		61933053D
B		Fire Bucket	1	61933053B	E		Lower Grill		61933053E
C		Ice Bucket	1	61933053C	F		Fork		61933053F

STEP 1:

To use the fire pit, firstly remove the centre tray and place to one side.



STEP 2:

Place the coal bucket (B), followed by the lower grill (E), then the upper grill (D), when your fire is lit, place the spark guard (A) over the fire.

